## § 1048.130

(h) Owners manual. Explain the owner's responsibility for proper maintenance in the owners manual.

 $[70~{\rm FR}~40468,~{\rm July}~13,~2005,~{\rm as}~{\rm amended}~{\rm at}~73~{\rm FR}~59233,~{\rm Oct.}~8,~2008;~75~{\rm FR}~23021,~{\rm Apr.}~30,~2010]$ 

## § 1048.130 What installation instructions must I give to equipment manufacturers?

- (a) If you sell an engine for someone else to install in a piece of nonroad equipment, give the engine installer instructions for installing it consistent with the requirements of this part. Include all information necessary to ensure that an engine will be installed in its certified configuration.
- (b) Make sure these instructions have the following information:
- (1) Include the heading: "Emission-related installation instructions".
- (2) State: "Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.".
- (3) Describe the instructions needed to properly install the exhaust system and any other components. Include instructions consistent with the requirements of §1048.205(v).
- (4) Describe the steps needed to control evaporative emissions, as described in §§ 1048.105 and 1048.245.
- (5) Describe any necessary steps for installing the diagnostic system described in §1048.110.
- (6) Describe any limits on the range of applications needed to ensure that the engine operates consistently with your application for certification. For example, if your engines are certified only for constant-speed operation, tell equipment manufacturers not to install the engines in variable-speed applications. Also, if you need to avoid sustained high-load operation to meet the field-testing emission standards we specify in §1048.101(c) or to comply with the provisions of §1048.101(d), describe how the equipment manufacturer must properly size the engines for a given application.
- (7) Describe any other instructions to make sure the installed engine will operate according to design specifications

in your application for certification. This may include, for example, instructions for installing aftertreatment devices when installing the engines.

- (8) State: "If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.".
- (c) You do not need installation instructions for engines you install in your own equipment.
- (d) Provide instructions in writing or in an equivalent format. For example, you may post instructions on a publicly available Web site for downloading or printing. If you do not provide the instructions in writing, explain in your application for certification how you will ensure that each installer is informed of the installation requirements.

[67 FR 68347, Nov. 8, 2002, as amended at 70 FR 40469, July 13, 2005]

## § 1048.135 How must I label and identify the engines I produce?

- (a) Assign each engine a unique identification number and permanently affix, engrave, or stamp it on the engine in a legible way.
- (b) At the time of manufacture, affix a permanent and legible label identifying each engine. The label must be—
- (1) Attached in one piece so it is not removable without being destroyed or defaced.
- (2) Secured to a part of the engine needed for normal operation and not normally requiring replacement.
- (3) Durable and readable for the engine's entire life.
  - (4) Written in English.
- (c) The label must—
- (1) Include the heading "EMISSION CONTROL INFORMATION".
- (2) Include your full corporate name and trademark. You may identify another company and use its trademark instead of yours if you comply with the provisions of §1048.635.
- (3) Include EPA's standardized designation for the engine family (and subfamily, where applicable).
- (4) State the engine's displacement (in liters); however, you may omit this from the label if all the engines in the